FixItSmartly - Engine Inspection Guide

Printable Repair Guides

Branded by FixItSmartly

Quick Reference Repair Tips Keep This Handy in Your Toolbox or Garage

OIL CHANGE

- 1. Warm up the engine for a few minutes.
- 2. Remove oil drain plug and drain old oil.
- 3. Replace oil filter.
- 4. Reinstall drain plug and add new oil.
- 5. Check oil level with dipstick and top off if needed.

BATTERY REPLACEMENT

- 1. Turn off the car and wear safety gloves.
- 2. Disconnect negative (-) terminal first, then positive (+).
- 3. Remove battery hold-down and old battery.
- 4. Install new battery, connect positive (+) terminal, then negative (-).
- 5. Secure battery and check for proper start.

AIR FILTER REPLACEMENT

- 1. Open air filter box under the hood.
- 2. Remove old filter and clean out debris.
- 3. Insert new filter in the same orientation.
- 4. Close and secure the filter box.

FixItSmartly - Engine Inspection Guide

TIRE PRESSURE CHECK

- 1. Use a tire gauge to check PSI.
- 2. Inflate or deflate as needed to match manufacturer spec.
- 3. Check all four tires and the spare.

WIPER BLADE REPLACEMENT

- 1. Lift wiper arm and press release tab.
- 2. Slide out old blade and snap in new one.
- 3. Gently lower the wiper back on the windshield.

SPARK PLUG REPLACEMENT

- 1. Disconnect the spark plug wire.
- 2. Use a spark plug socket to remove the old plug.
- 3. Check the gap on the new plug.
- 4. Install the new spark plug and reconnect wire.

Pro Tip: Keep this printed in your glove box or workspace for fast DIY help anytime.

Stay smart. Stay safe. Fix it rightFixItSmartly.